


HOW TO SETUP

 TentCraft | **MONARCHFLAG**


16ft Freestanding Custom Printed Event Flag




1 Place your base in its desired location and unfold it until it clicks into place.



2 Attach custom-printed flag to flagpole by sliding the loops down the flagpole.



3 Locate "L" hardware pole. Slide this into the top pole pocket of the flag softgood.




4 Attach the "L" bracket to the top of the vertical flag pole (pro-tip, you can lean the pole over to reach the top more easily).

Be sure the horizontal bar is seated fully into the connector.



- 5** Extend the flag up by pressing the push buttons along the vertical pole (there are 3 sections).



- 6** Place TentCraft footplate on the center footpad of flag to properly ballast.



- 7** Wrap cover around the base, zip it closed and attach with the snaps along the bottom.



- 8** Enjoy your beautiful flag!



Tent**Craft**.com/support

